

Dr. Fixit Corner Joint Tape



WATERPROOFING FLASHING TAPE FOR CONSTRUCTION JOINTS

Description

Dr. Fixit Corner Joint Tape is a specially coated 3-ply elastic tape with high extension in cross direction and rigid lengthwise, thin, high tenacity system component which when used in combination with Dr. Fixit® waterproofing products reduces the risk of leaks through potential cracking locations at wall corners, floor-to-wall connections, pipe entries etc.

Areas of Application

Waterproofing flashing tape used in combination with Dr. Fixit® waterproofing products for reducing the risk of leakage at locations at high risk to cracking recommended for:

- Residential or commercial wet rooms, kitchen & laundry areas.
- Swimming pools and water retaining structures in combination with ceramic coverings.
- Balconies and terraces.
- Interior and exterior use.

Features and Benefits

- Specially rubber coated 3-ply Fleece-lined tape.
- Good Crack bridging, accommodating any cracks in the substrate formed at a later stage.
- Impermeable to Water.
- Can be used both indoors and outdoors.
- Excellent adhesion to all the waterproofing products.
- Resistant to chemicals, can be used in chlorinated swimming pools.

Method of Application

1 GENERAL SURFACE PREPARATION

- Surface must be clean, dry and in sound condition to ensure adequate adhesion.
- Remove all oil, grease, dust, loose particles, and other foreign material.
- Fill all cracks, voids and bug-holes with an appropriate Crack Filler. Any surface defects should be repaired prior to application of membrane.
- Grind the, smooth finishing of wall and slab and make it rough to receive the coating.

2 TAPE APPLICATION:

- Cut to the appropriate size Dr. Fixit Corner Joint Tape using scissors or a razor knife.
- Embed Dr. Fixit Corner Joint Tape into the 1st layer of the wet Dr. Fixit® waterproofing product using a brush, roller, smoothing trowel, or spatula. The tape is placed upto 60mm on vertical and on horizontal surface of the corner joint. The applied tape should be ensured to be free from any crease.
- Overlaps must be ≥ 50 mm. On top of the cured and hardened 1st layer and tape, apply a 2nd layer of the Dr. Fixit® waterproofing product. The waterproof coating should be extended min.20mm beyond the tape width. Cure it appropriately and continue the waterproof coating on the entire area as recommended in the product datasheet.
- The inner and outer corners areas require special care and recommend proper dressing with Joint Tape.
- For pipes, use Dr. Fixit Pipe collar with minimum 4 mm of the stretchable part in contact with the pipe surface. Embed the collar with the Dr. Fixit® waterproofing product as explained earlier.
- Make sure the tape and collar are fully covered when applying the waterproofing material to the entire area.



Precautions & Limitations

- Follow all the application process as recommended for Dr. Fixit ® waterproofing products.
- Do not use sharp objects/ tools during corner joint tape application.
- Protect finished work from traffic until fully cured.
- The corners should be first treated before moving for waterproofing application.
- Ensure the corner tapes are free from any creases

PROPERTY	TEST METHOD	RESULTS
Color	Internal	Grey
Length	Internal	25 meters
Width	Internal	120 mm
Thickness	Internal	0.7 mm
Tensile Strength-Longitudinal	ISO 527-3:2018	10 N/mm ²
Tensile Strength-Transverse	ISO 527-3:2018	2 N/mm ²
Elongation at Ultimate load -Longitudinal	ISO 527-3:2018	70%
Elongation at Ultimate load -Transverse	ISO 527-3:2018	300%
Hydrostatic Pressure Resistance	EN 1928: 2000, Method B	>1.5 bar
Chemical Resistance	Internal	Resistant

Packaging

120mm wide x 25-meter-long roll.

Shelf Life & Storage

- Keep the tapes closed away from heat and flame when not in use; store in a cool & dry place.
- 12 months from the date of manufacture in unopened & proper storage conditions.

Other Products Categories available

Dr. Fixit brings you the widest range of Construction Chemicals



Pidilite Industries Limited

Construction Chemicals Division
 Ramkrishna Mandir Road, Post Box No. 17411
 Andheri (E) Mumbai 400059 INDIA
 Tel +91-22-2835 7000 • Fax +91-22-2835 7008
 www.drfixit.co.in • info.drfixit@pidilite.com
 Dr. Fixit Advice Centre (Toll Free No.) 1800 209 5504

DISCLAIMER The product information & application details given by the company & its agents has been provided in good faith & meant to serve only as a general guideline during usage. Users are advised to carry out tests & take trials to ensure on the suitability of products meeting their requirement prior to full scale usage of our products. Since the correct identification of the problems, quality of other materials used and the on-site workmanship are factors beyond our control, there are no expressed or implied guarantee / warranty as to the results obtained. The company does not assume any liability or consequential damage for unsatisfactory results, arising from the use of our products.