

# Dr. Fixit Triflex Primer 610



SINGLE-COMPONENT FAST-CURING PRIMER FOR TPO, FPO AND EPDM MEMBRANES

## Description

Dr. Fixit Triflex Primer 610 is a single component fast-drying primer for TPO, FPO and EPDM membranes before application of Dr. Fixit Triflex range of PMMA waterproofing and detailing system. The primer can be applied with a brush or a roller or by spraying.

## Features & Benefits

- Single Component
- Fast Curing
- Adhesion to various plastic and rubber membranes

## Method of Application

### Conditions for use

- Dr. Fixit Triflex Primer 610 can be applied at substrate and ambient temperatures between +5°C and +35°C.

### Preparation of the substrate

- The substrates to be primed must be sound, dry and free of loose or adhesion-reducing particles. Substrate adhesion must always be tested beforehand, or the Dr. Fixit technical department should be contacted. During application, the surface temperature must be at least 3°C above dew point. Below that, a separating film of moisture can form on the surface to be worked on (DIN 4108-5, table 1). See dew point temperature table.

### Application of Primer

- Before applying the product, stir or shake the contents until homogeneous. Apply a thin layer of Dr. Fixit Triflex Primer 610 using a short-pile roller or a brush consumption of 40-80 ml/m<sup>2</sup>. Make sure the application layer is not too thick. Once the Dr. Fixit Triflex Primer 610 has fully hardened, it can be further processed.

## Technical Properties

PROPERTIES	TYPICAL VALUES
Colour	Yellowish
Density	0.9 g / cc
Viscosity	15 mPas
Recoating time @ 30°C	15 mins
Rainproof @ 30°C	15 mins

## Recommended Consumption

Minimum 40-80 ml/m<sup>2</sup> on a smooth, even surface in one coat.

The specified consumptions apply only to smooth, even surfaces. Special allowances must be made for unevenness, roughness and porosity etc.

## Packaging

Dr. Fixit Triflex Primer 610 - 0.5 litre metal can (Yellowish colour).

## Shelf life & Storage

Can be stored unopened and unmixed for approx. 24 months in a cool, dry place above freezing. Keep container away from direct sunlight when in storage and on the construction site.



## Health & Safety Precautions

During application wear protective clothing, gloves and eye goggles during application. Avoid product to contact eyes and skin. Skin Contact - Wash immediately with plenty of clean water. Eye contact - In the event of eye contact splash plenty of clean water immediately and seek medical advice.

## Other Products Categories available

Dr. Fixit brings you the widest range of Construction Chemicals



### Pidilite Industries Limited

Construction Chemicals Division  
 Ramkrishna Mandir Road, Post Box No. 17411  
 Andheri (E) Mumbai 400059 INDIA  
 Tel +91-22-2835 7000 • Fax +91-22-2835 7008  
 www.drfixit.co.in • info.drfixit@pidilite.com  
 Dr. Fixit Advice Centre (Toll Free No.) 1800 209 5504

**DISCLAIMER** The product information & application details given by the company & its agents has been provided in good faith & meant to serve only as a general guideline during usage. Users are advised to carry out tests & take trials to ensure on the suitability of products meeting their requirement prior to full scale usage of our products. Since the correct identification of the problems, quality of other materials used and the on-site workmanship are factors beyond our control, there are no expressed or implied guarantee / warranty as to the results obtained. The company does not assume any liability or consequential damage for unsatisfactory results, arising from the use of our products.