



Dr. Fixit Crack-X Paste

READY TO USE FIBER REINFORCED POLYMER MODIFIED PASTE FOR INTERNAL AND EXTERNAL CRACK REPAIR

Description

Dr. Fixit Crack-X Paste is made from high-quality, weather-durable acrylic emulsion polymer, carefully selected graded fillers, light-fast pigments, and additives. It is a single-pack, ready-to-use flexible putty designed for filling cracks in plastered surfaces. It offers excellent bonding, ease of application, water resistance, aesthetic appeal, and durability.

Specification

Meets the requirements of ASTM C 834 - 91 standard.

Typical Applications

Internal & external Plastered brick masonry wall cracks of up to 5 mm width.

Features

- Permanent crack filling ability - Due to elastic polymers and micro fibers which gives long lasting permanent crack sealing
- Ease of application - it can be applied in crack gap up to 5mm.
- Flexibility - Flexible, therefore does not crack & accommodates minor movements in cracks.
- Paint ability - Over coatable by any type of polymer based paints, after 6 hours.
- Bonding - Excellent adhesion with cementitious surface.
- Toxicity - Non toxic- user-friendly non Hazardous.

Method of Application

1 SURFACE PREPARATION

- Ensure that the surface is free from dust, oil, grease, and loose particles. Before applying Dr. Fixit Crack-X Paste, moisten the surface.
- Widen all fine hairline cracks with a width greater than 0.50mm to a minimum of 3-5 mm using a scraper or cutter, creating a 'V' groove and fill with Dr. Fixit Crack X Paste.
- When applying Dr. Fixit Crack-X Paste on internal surfaces, make sure to remove any existing POP (Plaster of Paris) or painter's putty until the plaster surface is exposed.

2 APPLICATION

- Apply the primer coat prepared with Dr. Fixit Crack-X Paste and water in 1:1 proportion over the crack surface. Fill cracks with Dr. Fixit Crack-X Paste when the surface is tacky and not dried completely.
- Press Dr. Fixit Crack-X Paste firmly into the crack using a spatula or putty knife, and ensure it is level with the surface.
- Take care to prevent the formation of cavities or bubbles during the application. Allow the coat to dry for 4-6 hours.
- For internal walls further application of POP or painter's putty can be done once it is fully dry.

Precautions & Limitations

- Should not be used for cracks more than 5 mm thick.
- Not for application in cracks in structural members, expansion joints & separation gaps.
- Not for cracks in POP or painter's putty.
- For application below 10°C, drying time will be delayed.
- Container to be tightly closed after application.
- Allow Crack- X paste to dry for 8 Hrs before POP or painting.

Cleaning

Clean tools & equipment and hands with soap and warm water, immediately after use.



Technical Information

PROPERTIES	RESULTS
Appearance	White Paste with Fibre
Density gm / ml @30°C	1.38 to 1.46
Solid Content % @30°C	78 to 82
Viscosity Brookfield PS @30°C	500 to 800
Tack Free Time	Min 10 - 30
Elongation %	60 - 70
Tensile strength Mpa	12
Shore A	70-75
Shrinkage %	18 - 20

The values in the above table are obtained in controlled lab conditions when tested properly by competent laboratory.
Note: Tolerance up to 5% on the lower side of the above values is allowable.

Coverage

25-30 running meter/kg (for a depth of 5 mm and width of 5 mm).

Packaging

300, 500 gm, 1 & 5 kg

Shelf Life

- Shelf life is 12 months from date of manufacturing in unopened containers.
- Store at cool & dry place, away from sun heat.

Health & Safety Precautions

- Use rubber hand gloves & safety goggles, while using Dr. Fixit Crack X paste.
- In case of contact with skin, wash with plenty of water.
- Keep out of reach of children's.
- Should any of the products be accidentally swallowed do not induce vomiting but call for medical assistance, immediately.

Other Products Categories available

Dr. Fixit brings you the widest range of Construction Chemicals



Pidilite Industries Limited
Construction Chemicals Division
Ramkrishna Mandir Road, Post Box No. 17411
Andheri (E) Mumbai 400059 INDIA
Tel +91-22-2835 7000 • Fax +91-22-2835 7008
www.drfixit.co.in • info@drfixit.co.in

Dr. Fixit Advice Centre (Toll Free No.) 1800 209 5504

DISCLAIMER The product information & application details given by the company & its agents has been provided in good faith & meant to serve only as a general guideline during usage. Users are advised to carry out tests & take trials to ensure on the suitability of products meeting their requirement prior to full scale usage of our products. Since the correct identification of the problems, quality of other materials used and the on-site workmanship are factors beyond our control, there are no expressed or implied guarantee / warranty as to the results obtained. The company does not assume any liability or consequential damage for unsatisfactory results, arising from the use of our products.