

# PRE APPLIED FULLY BONDED HDPE WELDABLE MEMBRANE

## Description

**Dr. Fixit Prebond W** membrane is a preformed pre- applied HDPE fully bonded weldable membrane that bonds to the wet concrete cast on the membrane. After the membrane bonds with the concrete it forms an integral seal which prevents lateral water migration and makes it unaffected by any substrate settlement below the slabs. Reinforcement can be directly laid on top of the membrane and it does not require screed protection.

Dr. Fixit Prebond W is a unique HDPE membrane comprising of a HDPE layer and a pressure sensitive adhesive layer which is covered by a weather proof protective layer. The adhesive layer is activated when the concrete is poured on the membrane and it enables the membrane bond to underside of the concrete which prevents the ingress of water into the structure as well as prevents tracking of water between the membrane and the structure and provide a positive side protection against ingress of sub soil water. Dr. Fixit Prebond W can be used for horizontal application.

## Standard compliance / Specification

Complies with IS 16471:2017 & BS 8102:2009 recommendations for providing Type A protection

## **Typical Application**

- Basements
- Subway and UG metro Stations
- Cut and cover tunnels
- Caverns
- Other underground civil structures.

### Features

- Joints and overlaps are hot-welded to ensure zero leakage through lap joints.
- Excellent Adhesion with concrete placed over the membrane, to protect the structure effectively, from the positive side.
- Low flatness requirement to substrate; reliable overlapping; fast and easy application.
- Lesser joints and overlaps, due to large roll widths.
- Adaptable to varying surface profile of the substrate.
- Resistant to high hydrostatic ground water-pressure
- Resistant to acid, alkali, chlorides and sulphate attack
- Excellent water-tight joints due to welding

### Method of Application

- 1 SURFACE PREPARATION
- It is essential to prepare sound and levelled substrate with no gaps, cavities or projecting ribs..
- Horizontal Surface Monolithic concrete blinding must be free of loose aggregate and sharp protrusions. The surface does not need to be dry. However, standing water must be removed.
- Vertical Surface Use concrete, sacrificial plywood, masonary with flush levelled joints or other approved facing to provide smooth, level and even support to the membrane.

2 MEMBRANE INSTALLATION

• Dr. Fixit Prebond W membranes can be applied at ambient temperatures of -4°C or above.

#### 3 HORIZONTAL SUBSTRATES

• Place the membrane with adhesive side facing the concrete pour and HDPE film side facing the substrate. End laps should be staggered to avoid a buildup of layers. Accurately position succeeding sheets to overlap the

 $\cap$ 



previous sheet by 100 mm along the marked selvedge.

- The HDPE membranes are welded together by hot-air welding. End laps and side laps should be with the weld size of minimum 50 mm in case of single weld system. In case of a double weld system, comprising of two parallel welds of 15 mm wide each with a 20 mm air channel gap in between the two weld lines.
- Large robotic hot air welders can be used for high speed hot air welding of membrane joints. A Leister Varimat V2 machine or Leister Twinny or other suitable equipment is recommended.
- After welding the overlap area should be covered with single sided hdpe tape or hdpe membrane to be cut in 100 mm width and fixed by using double sided adhesive tape above overlap area.
- Roll Ends and Cut Edges
  Overlap all roll ends and cut edges by a minimum of 100 mm and ensure the area is clean and free from contamination. Ensure to remove sand and adhesive from membrane before proceeding for welding at joints.

#### 4 VERTICAL SUBSTRATES

- For application of Dr. Fixit Prebond W on confined retaining walls it is recommended to carry out welding of side and end laps using hand operated hot air welding machine.
- Alternatively Dr.Fixit Prebond PRO also can be recommended for waterproofing of confined retaining walls and membrane to be applied as per methodology described in respective product TDS.

#### 5 CORNERS

• Internal and external corners should be pre-formed as per manufacturer instruction, overlapping the membrane with a minimum of 100mm selvedge by hot-air welding. Ensure that the apex of the corner is covered and sealed with welding.

## **Technical Properties**

PROPERTIES	TYPICAL VALUES	TEST METHOD
Colour	White/ Off White	Visual Observations
Thickness of Composite Membrane	1.2 mm	ASTM D 3767
Thickness of Bare HDPE film	0.85 mm	ASTM D3767
Tensile Strength (Bare HDPE Membrane)	>25 N/mm <sup>2</sup>	ASTM D412
Elongation (Bare HDPE Membrane)	>500 %	ASTM D412
Puncture Resistance	>1000 N	ASTM E154
Low Temperature Flexibility (-25°C)	Pass	ASTM D1970
Resistance to Hydrostatic Head	>70 Mtr	ASTM D5385
Peel Adhesion to Concrete	>1500 N/m	ASTM D903
Lap peel adhesion (welded joints)	>10000 N/mtr	ASTM D1876
UV Resistance	45 days	Internal Test Method

All test parameters are obtained under controlled Lab conditions.

## Limitations

- 1. Product is approved for uses only those specifically detailed in this product data sheet. Contact Pidilite technical services where any other use is anticipated or intended.
- 2. Technical properties may vary by 5 % due to practical challenges like variation in UTM machines, type of loading, sample preparation, thickness measurement and other manual errors. Contact Pidilite Technical Services in such situations.

Note: Tensile strength & elongation has been tested longitudinally. Results in transverse direction may vary.



## Packaging

20 mtr x 2.4 mtr roll @ composite thickness of 1.2 mm

## Shelf Life

The shelf life is typically 12 months if stored as per the recommendations in a covered and secured storage space.

## Other Products Categories available

Dr. Fixit brings you the widest range of Construction Chemicals





Pidilite

Pidilite Industries Limited

Construction Chemicals Division
 Ramkrishna Mandir Road, Post Box No. 17411
 Andheri (E) Mumbai 400059 INDIA
 Tel +91-22-2835 7000 • Fax +91-22-2835 7008
 www.drfixit.co.in • info.drfixit@pidilite.com
 Dr. Fixit Advice Centre (Toll Free No.) 1800 209 5504

DISCLAIMER The product information & application details given by the company & its agents has been provided in good faith & meant to serve only as a general guideline during usage. Users are advised to carry out tests & take trials to ensure on the suitability of products meeting their requirement prior to full scale usage of our products. Since the correct identification of the problems, quality of other materials used and the on-site workmanship are factors beyond our control, there are no expressed or implied guarantee / warranty as to the results obtained. The company does not assume any liability or consequential damage for unsatisfactory results, arising from the use of our products.